

TiteTop Installation Instructions

Step #1

Jeep TJ Shown



Undo Velcro and place clip over roll bar (both sides) slightly angled down

Re-thread Velcro back thru ring and leave slightly loose

Step #2



Insert Bow in both ends of clip and leave hanging downward

Step #3



Pushing on Bow near one end flex Bow upward (Bow should “snap” in place)

Note: If Bow will not flex and “snap” and lock upward trim bow in ½ inch increments until it will

Step #4



Once bow is in place tighten Velcro straps on both ends